63028

GPF63028000000G000

HI-FI

validity date
≥ 07/2020



External parts for thermostatic shelf mixer for five separate functions, with push-button on/off controls. Shelf made of black frosted safety glass.




Table A - Button plate symbol code available	
Code	**Description**
SP02766	"RAIN" ICON BUTTON PLATE
SP02767	"CASCADE" ICON BUTTON PLATE
SP02768	"ATOMIZER" ICON BUTTON PLATE
SP02769	"HANDSHOWER" ICON BUTTON PLATE
SP02770	"BODY JETS" ICON BUTTON PLATE
SP02771	"BATHTUB" ICON BUTTON PLATE
SP02772	"FOOT SPOUT" ICON BUTTON PLATE
SP02782	"WALL-MOUNTED WATERFALL" ICON BUTTON PLATE
SP02783	"WALL-MOUNTED ATOMIZER" ICON BUTTON PLATE

N°	Code	Description
1	SP02849	RING
2	SP02846	INDICATOR RING
3	SP01936	THERMOSTATIC CARTRIDGE
4	SP02844	PUSH-BUTTON CARTRIDGE
5	SP03364	SPACER
6	SP01942	FILTER
7	SP01937	FIXING RING NUT
8	SP02845	FIXING RING NUT
9	SP00610	GRUB SCREW
10	SP02227	GRUB SCREW

N°	Code	Description
11	SP02878	HANDLE
12	SP02879	HANDLE
13	SP02889	FINISHING PLATE
14	SP01933	EXTENSION
15	SP02851	EXTENSION
16	SP02884	EXTENSION
17	SP02850	PUSH-BUTTON
18	SP00002	SCREW COVER
19	SP02887	GLASS
20	SP02843	HEADVALVE

 This drawing, as required by law, may not be made public or reproduced without the written authorization of GESSI S.p.A. Copyright GESSI S.p.A.